

	Product Bulletin		00034
Category:	Multimedia	Date:	5/1/01
Subject:	VRX610 (Monitor lock)		

Description:

Using a CCA-389 cable in the back of the VRX610 you can input a video source. When you do this, now you can watch that video source and listen to one of the following: AM/FM, CD Changer, or TV Tuner. This is called Monitor Lock.

Follow this steps when the unit is open to get this done:

Press the OPEN / M-LOCK button that is on top of the unit.

• This will allow the video source from the CCA-389 to display on the screen.

Press the FUNC to get another source to play through the system.

Press the OPEN / M-LOCK to remove that video source from the screen.

AV010205